Published by Hutchison 3G Ireland Limited. All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. © 2006 Hutchison 3G Ireland Limited. A Hutchison Whampoa company.

Hutchison 3G Ireland Limited trading as **3** is a service provider and has provided the information in this user guide concerning what you might expect from **3** services. Sony Ericsson Mobile Communications AB is the manufacturer of the Z610i handset and has provided the information on its features and use set out in this user guide.

The contents are believed to be correct at the time of going to press, but any information, products or services mentioned may be modified, supplemented or withdrawn. The provision of any products and services by Hutchison 3G Ireland Limited is subject to **3**'s customer terms (available at three.ie). The customer terms will take precedence if there is any discrepancy with this publication.

'**3**a and related images, logos and names referred to in this publication are trademarks of the Hutchison Whampoa group of companies.

This publication is printed on fully recyclable paper.

DM06599 Oct06

Sony Ericsson | Z610i

3 services user guide

Get going.

Sony Ericsson | Z610i

Find out what your Sony Ericsson Z610i does.

Insert your USIM and battery 2

Find out what you can do on **Planet 3** 3

Handy information about your mobile 4

Get the most from your mobile 5

Make voice and video calls 6

Use camera and video, and play music 7

Text, multimedia and email messages 8

Set up your email 9

Transfer files between your mobile and PC 10

Helpful information 13

The sections in pink describe **3** services, and those in black describe Sony Ericsson services.

Please refer to the Sony Ericsson manufacturer's Z610i user guide for important safety information.

Insert your USIM and battery

Your 3 USIM can only be used in mobiles which are enabled for 3 services.

If you try and use the USIM in other mobiles you could seriously damage the mobile and may be unable to use it – including for emergency calls. We can't be responsible for any such damage or any resulting problems using your mobile.

Illustrations

1 Remove the battery cover

2 3 Insert your USIM and battery

4 Close the battery cover

5 Charge your battery

1

2



3

4

5

Fully charge the battery before using it for the first time.

Find out what you can do on Planet 3

From Planet 3 you can...
Watch music videos and goals, play games and much more. Just press the **Planet 3** button once and wait for a few seconds. It's free to browse and we'll tell you how much things cost before you download them.

Music
Download full length music videos and tracks.

Tunes & Pix
Personalise your mobile to look and sound unlike anyone else's.

Games
Buy a game and keep it forever or rent one and pay less.

Football
Get the latest news, match reports, live scores and video clips.

Internet
Get access to a selection of the best mobile websites.

All this plus news, showbiz, movie trailers, TV clips, comedy and more. It's all on Planet 3.

EMI Q SONY BMG BARCLAYS PREMIERSHIP SKY SPORTS KISS FHM

Handy information about your mobile

Icons on the top of the screen

- **3** video service area
- **3** voice & picture service area
- Alert profile – in this case silent
- Alarm set
- Multimedia messages
- Text message
- Battery strength

Get the most from your mobile

Set date and time
› **Settings (#)**

Select your ringtune
› **Settings (#)**
› **Sound & alerts** tab

Select your wallpaper
› **Settings (#)** ›
Display tab

Make a voice call
Enter the number and press **Call**

Send text, photo, video, email
Press ◀ for **Messages** menu

Back key
Press once to go back to the previous screen. Press for 5 seconds to return to start screen

Access voicemail
Press and hold 1 for voicemail

Shortcut keys
Settings (#) › press #
Calls (*) › press *
Contacts (8) › press 8

Send and receive email
First, you have to set up your email account – see page 9

Watch music videos and goals, play games and much more
Press and hold Planet 3 and wait a few seconds for **Planet 3**. It's free to browse. You'll be advised of any costs before downloading

Access soft boxes
Press left or right soft key once

Select alert profile
Press ▶ right

Clear character
Press C to clear character(s)

Add, find or edit a contact
Press down to find a contact. Press **More** to send or edit contacts

Power on / off

Navigate
Navigate left, right, up, down. Press to confirm

Make voice and video calls

Make calls

› Enter the number.

› Press **Call** for voice calls.

› Press **More** then Make video call for video calls.

› To end a call press **End call**.

Receive calls

› To answer a call press **Answer**.

› To end a call press **End call**.

› During a video call, you'll see a large picture of the other person and a small picture of how you look to them in the bottom left of the screen.

› To stop the other person from seeing you: press and scroll to **Stop camera**.

Set up voicemail and videomail

› To set up voicemail, press and hold 1.

Follow the voice prompts to choose a PIN and record your greeting.

› To set up videomail, enter 171 and press **More** then Make video call.

Follow the voice prompts to record your video greeting. The caller will see your video greeting when you can't answer a video call.

From you can...

View missed, received, dialled calls
Calls (*)

Activate call waiting
Settings (#) › Calls tab › Manage calls

Divert calls
Settings (#) › Calls tab › Divert calls

Send or withhold number
Settings (#) › Calls tab › Show / hide my no

View own number
Contacts (8) › More / Options › My business card

Use camera and video, and play music

Take and send photos and video clips

› Press .

› Press ◀ ▶ to select **camera** or **video**.

› Press to take a photo or to start and stop video recording. Press again to save the video.

› Select **Send** (left soft key) and follow menu.

You can control light, brightness, quality, file size and duration. In **Camera** or **Video camera** mode select **More** (right soft key).

Add a photo to your contact

You can associate a photo with a contact stored on the mobile and not your SIM card.

› Highlight the contact **› More › Edit contact ›** scroll left to and **› Add › Camera album.** Then select your preferred image **› Save**.

View photos or video clips

› **› File manager (7) › Camera album / Pictures / Videos.** Then select your preferred file.

Play music

› **› Entertainment (3) › Music player**.

Text, multimedia and email messages

› Press ◄ (left), then press to select text, picture message or email.

Send a text or multimedia message

› To send a text: write the message › **Continue** › **Contacts look-up** or **Enter phone no** › enter phone number › **OK** › **Send**.

› To send a multimedia message (picture message) to a mobile or email address: scroll to the icons at bottom of the screen › **Add picture / video / sound** › select your file › **Continue** › **Contacts look up** or **Enter phone no.** or **Enter email addr.** › enter contact details › **Send**.

Send and receive emails

› To send an email you first need to set up email on your mobile – see page 9.

› At **To:** enter email address or press for **Contacts look up** › Scroll to the text box › write your message › **Continue** › **Send**.

› To retrieve an email: › **Messaging** › **Email** › **Inbox** › **More** › **Send & receive**.

› To reply to an email: **Reply** (left soft key).

› To browse into Mail: press and select Go to Services. Scroll to **Mail** and press .

From the browser you can send emails and view and manage emails, voicemails, faxmails and contacts.

Help with entering text

› To switch between lower case, upper case and predictive text, press .

› To enter numbers, press the specific key for 3 seconds.

› To insert a symbol, template, emoticon or contact number, select **More** (right soft key).

› To insert a space, press .

Set up your email

Set up your username

To set up your **3mail** you need to have set up a voicemail PIN first.

› Press and select Go to Services. Scroll to **Mail** and press .

› Scroll to **Enter username** and press for the text prompt. Key in your preferred username (eg johnsmith), scroll down to **Done** and press . Then press .

› If this name has already been taken you will be asked to choose again. Once your username has been accepted your email address will be eg johnsmith@3mail.com

Set up your profile

› › **Messaging** › **Email** › **Settings** › **3Mail** › **More** › **Edit account**.

› Scroll to **Username** and key in your mobile number starting with 3538xxxxxxxx but without plus (+). Scroll down to **Password** and key in the 4-digit PIN you selected for voicemail. Scroll up to **Email address** and key in your email address (eg johnsmith@3mail.com).

You're now ready to send and receive emails from your **3mail** account.

Collect emails from other accounts

To collect emails from other accounts you need to set up your POP3 email account.

› Press and select Go to Services. Scroll to **Mail** and press . Scroll to Mail and press . Scroll to **Settings** and press . Scroll to **Manage other mail** and press . At **Add new account** press .

› Scroll to **Name this account**, press for the text prompt and enter a name for the account. Then do the same in turn for **POP3 server address**, **POP3 Username**, and **POP3 user password** and select **Done** and press .

You can check these details with your email / internet service provider.

You're now ready to collect emails from another email account.

Help with entering text

› To switch between lower case, upper case and predictive text, press .

› To enter numbers, press the specific key for 3 seconds.

Transfer files between your mobile and PC

You'll need: Windows 2000 Professional or Windows XP Home or Professional; a USB port and CD-ROM drive.

Install the file transfer software

› Load the **Sony Ericsson CD** that came with your mobile on to your PC. The installation should begin automatically, otherwise select **Run** on your PC, and enter **D/E: start.exe** to install **PC Suite and Disc2Phone.** Then follow the Wizard to install.

Connect mobile and your PC

› Connect your mobile and PC using the USB cable. It will automatically install drivers to connect your mobile and PC.

› Select **Phone Mode** on your mobile.

Customise synchronisation settings

› Right click on **My Sony Ericsson Z610i** in the bottom right corner of your PC.

› Select **Sync Manager.**



Right click on the **My Sony Ericsson Z610i**

In the pop up screen

› Select **Sync Manager.**

› Select **Settings** and click **Next**.

› Select the PC application, eg **Microsoft Outlook**, to synchronise with your mobile. Click **Next**.

› Select which items you want to synchronise, eg **Calendar** or **Contact**. Then click **Next** and the synchronisation will start.

› Select **Advance Sync** for further settings. Please read the different features carefully and then select the appropriate feature for synchronisation.

Synchronise contacts and calendar

› Make sure your mobile and PC are connected using the USB cable.

› Right click on in the bottom right corner of your PC and select **Synchronise Now** to start the synchronisation.

Transfer files between your mobile and PC

Transfer images and videos

› Make sure your mobile and PC are connected using the USB cable.

› Right click on **My Sony Ericsson Z610i** in the bottom right corner of your PC.

› Select **File manager**.

In the pop up screen

› Select **My Sony Ericsson Z610i**.

› Select **Memory Stick / Phone memory.**

Then drag and drop relevant picture, audio or video between your mobile and PC.



In some cases you'll need to convert files, for example to view a video on your PC in Windows Media Player that you captured on your mobile, or to listen to an audio file that you transferred to your mobile. You'll find a number of converters to download in the **Existing customer** section of **three.ie**

Please note that transferring copyright-protected content, eg music and football videos, without the copyright owner's consent is against the law and it breaks your agreement with **3**.

Helpful information

- Visit **three.ie**
- Email **customer.services.ie@3mail.com**
- Call **Customer Services** on 333 (083 3333 333 from another phone).

Contact Centre
3 Customer Services
Hutchison 3G Ireland Ltd
PO Box 333
Dublin 2
Ireland

Useful numbers

	Mobile	Other phones
3 customer services	333	083 3333 333
Mail (voicemail, email and faxmail)	1 (3 secs)	083 3333 171
Videomail	171 (Select video call option)	
Directory enquires	118 11	118 50
International directory enquires	118 18	118 60
Emergency calls	112	112

Getting the most from your battery

- You can recharge your battery several hundred times before it will need replacing and you don't need to fully discharge it before recharging.
- Don't expose the battery charger to direct sunlight or use in areas of high humidity such as a bathroom. Battery life will decrease if you expose it to temperatures below -10°C or above 45°C.
- If you charge your battery regularly and you notice a decrease in talk time or an increase in charging time, then it's probably time to buy a new battery.